SGARIFYING AND RIPPING



Front mounted ripper-scarifiers are generally used for light work.

Some tips for using a ripper-scarifier:

- 1. Drive the grader in straight passes to create more traction with the attachment and the materials.
- 2. Use low gears and less rpms to avoid the tires slipping.
- 3. Only ever use the correct amount of shanks for the work task.
- 4. Slowly lower the shanks of the ripper-scarifier attachment into the materials while travelling straight.
- 5. Only use one ripper shank when ripping extremely hard materials.
- 6. Never use a single scarifier shank in hard materials.
- 7. Do not use badly worn or missing shank tips as this will damage the attachment.